

**VILLAGE OF DOWNERS GROVE
REPORT FOR THE VILLAGE COUNCIL MEETING
MARCH 20, 2012 AGENDA**

| SUBJECT: | TYPE: | SUBMITTED BY: |
|-----------------------------------|--|--|
| Purchase of Replacement Ambulance | Resolution Ordinance ✓ Motion Discussion Only | Nan Newlon, P.E. Director of Public Works |

SYNOPSIS

A motion is requested to authorize the purchase of a 2013 Freightliner M2/MedTec M170 ambulance from Foster Coach Sales of Sterling, Illinois in the total amount of \$221,794.

STRATEGIC PLAN ALIGNMENT

The goals for 2011-2018 for include *Exceptional Municipal Services*.

FISCAL IMPACT

The adopted FY12 budget includes \$220,000 in the Equipment Replacement Fund for the purchase of a replacement ambulance. Sufficient budget authority is available in the Equipment Replacement Fund for this purchase, as the other 11 vehicles and pieces of equipment scheduled for replacement in 2012 are under budget by a total of \$24,000.

UPDATE & RECOMMENDATION

This item was discussed at the March 13 Village Council meeting. Staff recommends approval on the March 20 Consent Agenda.

BACKGROUND

The 2012 vehicle replacement schedule consists of 15 vehicles and pieces of equipment. The Village plans to purchase a total of 12 vehicles this year, 11 of which are being considered the Consent Agenda tonight. The table below shows the vehicle that staff is currently recommending for purchase.

| Quantity | Type of Vehicle | Make and Model | Dealer | Price |
|----------|-----------------|----------------------------------|---|-----------|
| 1 | Ambulance | 2013 Freightliner MedTec M170 | Foster Coach Sales of Sterling, Illinois | \$221,794 |

The Village's Fleet Team, consisting of representatives from the Village Manager's Office and Finance, Public Works, Police and Fire Departments evaluated the need to replace the ambulance. All Village vehicles and equipment are targeted for replacement according to useful lifecycle replacement criteria. These criteria include age, usage, condition, repair costs, fuel efficiency and environmental impact. The Fleet Team reviewed the vehicles scheduled to be replaced and determined that the criteria for replacement were met in this case.

All Village vehicles and equipment are targeted for replacement according to a useful lifecycle replacement criteria guideline. The life expectancy of the ambulance is six years, for example, although the additional criteria noted above are also considered when making the final replacement recommendation.

It will take approximately 10 months from the time of order to take delivery of this vehicle which is planned to be in service in early 2013. The purchase is recommended to be made through a cooperative

purchasing contract in accordance with the provisions of the Village Purchasing Policy. The ambulance would be purchased through the Wisconsin EMS Association Group Buying Program, a joint purchasing program sponsored by the Wisconsin EMS Association.

ATTACHMENTS

Wisconsin EMS Association Cooperative Contract – Foster Coach Sales

QUOTATION

Foster Coach Sales, Inc.

Quote For:

DOWNERS GROVE FIRE DEPT.
6701 MAIN STREET
DOWNERS GROVE, ILL 60516

Ship To:

FOSTER COACH SALES, INC.
903 PROSPERITY DRIVE
STERLING, IL 61081

Exp. Date: 03/01/2012
Quote No: 10034-0004

03/01/2012

Job No:

Page 1

| PART NO | DESCRIPTION |
|------------|--|
| | == M170, 170" x 96", Type I - 11.009 12/14/11 == |
| | *** PRELIMINARY ADMIN/ COT INFORMATION *** |
| 00-00-0001 | CUSTOMER ORDER TEAM PROJECT OWNER: SHOP NOTE: (insert name here) (insert date here) |
| 00-00-0002 | SPECIAL NOTES TO MANUFACTURING |
| 00-00-0010 | PRODUCTION FACILITY, Bradenton FL |
| 01-00-0000 | VIN # |
| 01-02-0400 | Factory Discount/Concession SHOP NOTE: WEMSA MEMBER DISCOUNT |
| 01-02-0600 | Delivery Charges FOB Bradenton FL |
| | *** GENERAL VEHICLE DESIGN & REQUIREMENTS *** |
| 10-02-0800 | 2011 Base Conversion, M170, Type I AD |
| 11-06-1210 | 74" Headroom (M170)- Module 170"L x 95.5"H x 96"W SHOP NOTE: REQUIRES SP and engineering approval |
| 12-00-2600 | EXTERIOR "A" COMPTS. - PASS. SIDE (72-74" HR) M170 SHOP NOTE: LOCATION: Exterior compartments, passenger side. |
| | *** CHASSIS MAKE & MODEL *** |
| 12-09-1999 | No special Chassis Items required |
| 12-12-9900 | SPECIAL Freightliner, QID SHOP NOTE: INSTRUCTION: Signed chassis spec is required at time of order ____ " wheelbase ____ LB GVW ____ " Cab to Axle |
| 12-13-1700 | Rear Air Ride - OEM Airliner, Freightliner SHOP NOTE: |

| PART NO | DESCRIPTION |
|--|---|
| | Install dump cancel switch beside curbside rear entry door Dump automatically activated by the streetside rear entry door. OEM low PSI light in the OEM dash and dump indicator switch in the front switch panel. |
| 12-16-0100 | Exhaust - Passenger Side Rear of Rear Axle |
| *** CHASSIS COMPONENTS *** | |
| 14-17-0001 | Anti Sway Bar(s) OEM |
| 14-26-0600 | Additional Aux. AC Compressor (FL) SHOP NOTE: INSTRUCTION: |
| *** CHASSIS INTERIOR COMPONENTS *** | |
| 16-11-0110 | Cab Dome Light - Weldon 8086-6978-68 Red/Clear Split SHOP NOTE: MOUNT IN CENTER OF CAB ROOF |
| 16-12-0400 | Bulkhead Cab Wall, OEM Wall To Match Dash |
| 16-14-0400 | Cab Sign, "No Smoking Oxygen Equipped" & "Fasten Seatbelts" SHOP NOTE: Install on top of floor console at rearward edge toward bulkhead wall. |
| 16-16-0200 | Cab Flooring, OEM |
| 16-20-0700 | Map Box, Bulkhead Mounted, (4) Adj. Shelves SHOP NOTE: Cabinet to be 14" W x 28"T X 5.5" D (OD)) Install 4 angled smooth aluminum adjustable slots mounted flush to the unistrut on the back wall of the cabinet 8" long from the bend in the shelves. (Eliminate any gap between angled slot and wall and round off any sharp corners). Leave the top open Install Kydex , to match interior, on the sides of the vertical map slot storage cabinet in cab on bulkhead wall. |
| 16-21-0000 | Battery Switch - TST Commander 357 With Adj.Timer SHOP NOTE: Adjustable Battery switch will be set at 5 minutes unless otherwise specified |
| 16-22-0200 | Anti-Theft - ETI Ignition Security w/Alarm & Kill Feature SHOP NOTE: Hang activation switch loose under dash until exact location has been chosen by customer. |
| 16-24-0200 | Summer Switch for Block Heater SHOP NOTE: Install behind the driver's seat in cab Requires block heater on chassis spec to be an active option. |
| 17-14-0409 | RE-INFORCE FLOOR FOR FUTURE INSTALL S STRYKER POWER LIFT *** CHASSIS EXTERIOR ACCESSORIES *** |
| 18-06-9700 | DELETE STAINLESS WHEEL COVERS SHOP NOTE: CHASSIS HAS ALUMINUM WHEELS DEALER TO INSTALL TOP HATS |

| PART NO | DESCRIPTION |
|--|---|
| *** 12 VOLT ELECTRICAL SYSTEMS AND COMPONENTS *** | |
| 20-02-0800 20-08-0600 | Standard Electrical System Install and Label Breakers SHOP NOTE: Install and label where required, in the electrical cabinet |
| 21-02-0000 | Portable Equipment Charging Circuits SHOP NOTE: (1) 20 amp circuit breaker. Run power wires from under front console to: (1) Circuit (power & ground) to front console labeled on both ends: "Portable Equipment Charging Circuit". (1) Circuit (power & ground) to behind rear switch panel labeled on both ends: "Portable Equipment Charging Circuit". |
| 22-02-0600 | Sequencer/Load Manager, Main Master Emergency Functions SHOP NOTE: INSTRUCTION: Medtec sequencer and load manager. Standard shedding sequence. |
| 22-04-2200 | Front Console, Center Cab Mount, Type I Wood SHOP NOTE: INSTRUCTION: Install standard floor-mounted console. Install Rocker style switch panel in the dash/console |
| 22-05-0100 | Front Switch Panel Assembly, Standard Electrical System SHOP NOTE: Install in front center console |
| 22-08-9900 | OPEN DOOR INDICATOR LIGHT SHOP NOTE: WHELEN #5COCCCR RED 500 LIGHT WITH FLANGE MOUNTED BETWEEN THE SUNVISORS TO FLASH WITH PATIENT ENTRY OR COMPARTMENT DOOR OPN |
| 22-09-0010 | Digital Voltmeter/Ammeter, InPower DSP-DSC1, Standard SHOP NOTE: Wire to batteries. (1) ammeter sensor. Install in front switch panel. |
| 22-09-0201 | Hourmeter, Delete SHOP NOTE: DELETE HOURMETER AS CHASSIS HAS IN THE DASH |
| 22-12-0800 | Radio Cover in Cab With Black Kydex Covers SHOP NOTE: INSTRUCTION: [2] Custom cutout for installation of a radio, installed in the cab - with a 1/4" black Kydex cover. MOUNT BELOW HEAT/AC CONTROLS AND ABOVE THE SIREN HEAD |
| 24-02-1800 | (3) Batteries, Total 1950 CCA (MD Std.) SHOP NOTE: INSTRUCTION: All (3) OEM located under the driver's side cab step. |

| PART NO | DESCRIPTION |
|---|---|
| 24-12-0400 | Outlets, (2) 12 Volt, Power Point Style (Std. Location) SHOP NOTE: (1) in upper ALS cabinet (1) on 1st action area wall with cover(s) included SEE PRINTS |
| 24-12-3400 | Additional 12 Volt Prewire, Coiled SHOP NOTE: LOCATION: [1] IN D-4 #3 WALL UPPER FORWARD CORNER [1] IN D-2 #1 WALL UPPER FORWARD CORNER [1] IN FRONT CONSOLE FOR FUTURE USE--POWER/GROUND/IGNITION |
| 24-12-3600 | Outlet, (Qty) Additional 12 Volt, Power Point Style SHOP NOTE: with cover(s) included [1] IN NOTEBOOK STORAGE AREA [1] IN ACTION AREA TOWARDS THE REAR [1] IN THE REARWARD STEETSIDE COMPARTMENT AT THE FOWARD FLOOR SECTION PER PRINT |
| *** 125 VOLT ELECTRICAL SYSTEMS AND COMPONENTS *** | |
| 26-04-0810 | Inverter/Battery Chrg., Vanner Lifestar 20-1050CUL-DC w/ rem SHOP NOTE: (1) On/off switch in the rear switch panel. Lifestar Inverter/Charge 20-1050CUL-DC 120V-60Hz with LSIR (Inverter Panel) and LSCR (Charge Panel) LSIR remote panel to be installed in first action area. LSCR remote panel to be mounted above shoreline input |
| 26-04-5010 | Inverter, Install in D2 Compartment SHOP NOTE: MOUNT ON UPPER FORWARD BACK WALL #2 PER PRINT |
| 26-10-120R | Shoreline, 20 Amp Kmaul Super Auto-Eject Driver Side RED SHOP NOTE: INSTRUCTION: RED cover (1) 125 volt 20 amp. (60Hz) Kusmaul Super Auto-eject MOUNT ON ANGLED WEDGE ON FORNT OF BOX Water-tight cover. Ship loose mating plug. |
| 26-10-4010 | Optional Mounting Plate, Kusmaul E-Z Mounting Plate SHOP NOTE: Kusmaul Part Number 091-185-009 |
| 26-10-5010 | No Angled Shoreline Mounting Bracket |
| 26-16-2800 | Outlets, (3) Interior, 125V SHOP NOTE: (1) in ALS cabinet (1) in 1st Action Area (1) in 2nd Action Area SEE PRINTS |
| 26-17-6400 | SPECIAL Outlets, (3) 125V Additional Interior, Locations |

| PART NO | DESCRIPTION |
|-----------------------------------|---|
| | SHOP NOTE: [1] IN CAB BEHIND PASSENGER SEAT [1] IN NOTEBOOK SLOT HORIZONTALLY REARWARD SEE PRINTS |
| 26-22-0500 | Spotlight, (1) Optronics "BlueEye 4000",Hand-Held, Hard Wire SHOP NOTE: LOCATION: SHIP LOOSE FOR CREDIT--DEALER WILL CREDIT THE CUSTOEMR FOR THE SPOTLIGHT SHIP LOOSE HANGING HARDWARE. |
| * * * AUDIO WARNING DEVICES * * * | |
| 28-02-1400 | Siren, Federal Signal, PA300-012MSC, 200 Watt |
| 28-04-0105 | Switch, Siren/AirHorn/Horn, 3-Position, Front G2 Vmux Displ SHOP NOTE: Icon in the front G2 Vmux display panel. |
| 28-06-2610 | Speakers (2) Bumper mounted Federal ES100 with ESFMT mount SHOP NOTE: speakers recessed into chassis bumper, one per side. (2)ES100 speakers (2) ESFMT mounting trim rings and brackets |
| 28-06-2700 | Speaker, Bumper Mtd, Federal BP-200EF, Flat Grille Cast Hsg SHOP NOTE: Fab to cut hole for speaker. |
| 28-08-9900 | SPECIAL Air Horn -FOOT SWITCH FOR AIR HORNS SHOP NOTE: DRIVER SIDE FOOT SWITCH FOR AIR HORNS WIRE TO EMERGENCY MASTER SWITCH |
| 28-08-9910 | SPECIAL, Air Horn Accessories #1 SHOP NOTE: Dealer to specify |
| 28-10-0100 | Chassis Provided Air Horn Switching Requirements SHOP NOTE: 3-Position switch in the front switch panel. |
| 28-10-0200 | NOTE: Horn Ring, Switch, Siren/Horn/Air Horn 3 Position ILO SHOP NOTE: INSTRUCTION: (3) position switch to toggle between siren/horn and air horn between each horn ring trigger. (1) switch in front switch panel |
| 28-12-0600 | Siren, E-Q2B, Electrical IATS SHOP NOTE: Break switch located in siren head |
| 28-14-0200 | Backup Alarm, EC520 With Auto Reset Switch SHOP NOTE: Install (1) momentary switch in front switch panel for auto reset. |
| 29-00-1250 | Back up 1-Camera , Rearview Observation System, Gentex SHOP NOTE: --#50-GENK352 3.5"RCD Kit, Auto Dimming Mirror Color CCD IR Audio |

| PART NO | DESCRIPTION |
|------------|--|
| | --#20-CM32AH BACKUP Camera WITH 55" CABLE |
| | --#20-DRN007 HARNESS |
| | Order from ASA |
| | --VCCS150 (Medtec Pt. #1008407 White Voyager color, high resolution camera with Microphone |
| | --#31300006 Camera Adapter |
| | --#CEC50 Camera Cable |
| | |
| | |
| | *** VISUAL WARNING/FLASH REQUIREMENTS *** |
| | |
| 30-00-0010 | Flasher, Halogen/LED/Super-LED, Whelen AFM560 SHOP NOTE: Install in electrical cabinet. |
| 30-00-0011 | Flasher, Additional Whelen for front lightbar SHOP NOTE: Required for Whelen Edgebar lightbar installation and will be installed in the front lightbar by Whelen. See wizard |
| 30-00-0012 | Flasher, Additional Whelen for rear lightbar SHOP NOTE: Required for Whelen rear lightbar for double, triple or quad flash and will be installed in the front lightbar by Whelen. See wizard |
| 30-00-001B | Flash Pattern, Double Flash (LED Only) SHOP NOTE: Double Flash. 75fps. Light will activate on and off twice per flash. |
| 30-00-002A | Rear Lightbar Flash Pattern, Single Flash (Default) SHOP NOTE: SingleFlash. 75fps. Light will activate on and off once per flash. |
| 30-03-1450 | Clearance Lights, (14) Whelen OS LED W/ Chrome Bezel M Std SHOP NOTE: Install (14) OS Series LED marker lights with chrome plated flanges. (7) Red LED/Clear Lens on rear body upper extrusion and rear side body upper extrusion. (7) Amber/Clear Lens on front upper body extrusion and front side body upper extrusion. SEE PRINT |
| 30-04-1000 | Headlight Flasher, Power Pulse Wig-Wag, SHOP NOTE: LOCATION: OEM chassis headlights. |
| 30-06-0200 | Headlight Flasher Mounting Location, Standard SHOP NOTE: LOCATION: (Standard) Flasher mounted in electrical cabinet |
| 30-06-0600 | Headlight Flasher Wiring, Standard |
| 30-09-4605 | B/T/T Lights, 900 LED with LED Backup Light SHOP NOTE: 900 RED LED Brake 900 Clear Max Intensity Backup 900 Amber LED Turn |

| PART NO | DESCRIPTION |
|---------------------------------------|---|
| | Each side |
| 30-09-8450 | + Select Rear of Module Auxillary light Options |
| CHASSIS GRILLE LIGHTS | |
| 30-17-9900 | SPECIAL Grille Light, (4) Lights/Lens Color - IATS SHOP NOTE: INSTALL 4 WHELEN M7 GRILL LIGHTS 2 UPPER AND 2 LOWER RED DRIVER SIDE UPPER AND LOWER DRIVER SIDE GREEN UPPER AND LOWER DRIVER SIDE TO FLASH IN "X" PATTERN |
| INTERSECTION LIGHTS | |
| 30-22-1000 | Intersection Lights, (2)Whelen 700 S. LED, R/C split ILOS700 SHOP NOTE: INSTRUCTION: Clear Lens RED Forward |
| 30-28-8005 | Flange(s),Intersection Lights, Whelen 700 Series LED/Halogen SHOP NOTE: INSTRUCTION: |
| LIGHTBAR(S) - FRONT OF VEHICLE | |
| 30-30-1860 | Front Lightbar, Whelen 86" LED Edgebar-#4500 w/ ELtube Red SHOP NOTE: INSTRUCTION: >>>> Special Whelen LED Lightbar <<<< 2 - Corner angled linear red LED, 4 - 400 series linear red LED flashers, 2--400 BLUE LEDS 2 - 4ELTUBES to be used as an opticom Lens Colors: R/R/B/R/C/C/R/B/R/R LED Colors: R/R/B/R/[2]4ELtubes/R/B/R/R (1) switch in front switch panel. Includes 02-0241912-01 Conductor Cable Includes Internal Flasher PE215 remotely installed. |
| FRONT MODULE BODY LIGHTS | |
| 32-02-0101 | ADDRESS LIGHTS--WHELEN PELCC ON FRONT OF BOX SHOP NOTE: INSTALL TOW [2] WHELEN PELCC LIGHTS VERITCAL MOUNT ON FRONT OF BOX FOR ADDRESS LIGHTS WIRE TO RESPECTIVE SIDE SCENE LIGHT SWITCHES PASSENGER SIDE WILL NEED TO MOUNT BACK TOWARDS THE CENTER TO CLEAR THE CHROME STACK AT TIME OF BODY BUILD AND MOUNT, DETERMINE IF IT CAN BE MOUNTED TO THE OUTSIDE AND CLEAR THE CHROME EXHAUST--IF SO, INSTALL AT OUTER EDGE OF BODY MOUNT DRIVER SIDE TO MATCH |

| PART NO | DESCRIPTION |
|--|--|
| SIDE MODULE BODY WARNING LIGHTS | |
| 32-16-1200 | Side Body Lts, 4 Whelen 900 Red Super-LED/Lens, (STD) SHOP NOTE: (4) 900 Series red Super-LED, red lenses Install (2) on streetside and (2) on curbside SEE PRINTS |
| 32-16-8020 | Flange(s), Whelen 900 Series Super-LED EA. |
| 32-18-0600 | Side Body Turn Lts., Whelen 700 LED SHOP NOTE: (2) 700 Series Red LED Turn/Tail lights with red lenses. Install (1) on each side of body at rear. Steady burn with DOT lights. Flash with turn signals. SEE PRINT |
| 32-18-5000 | Flange, Whelen 700 Series EA. |
| 32-20-6000 | Wheel Well Lts.,(2) Whelen 700 Super LED,R/C Split SHOP NOTE: LOCATION: With Flanges Mounted over rear wheelwells. Clear Lens RED Forward |
| 32-21-1000 | Flange(s), Wheel Well, Whelen 700 Series EA. SIDE SCENE LIGHTS |
| 32-22-0700 | Scene Lts, Whelen 900 Halogen Opti-Scene 8-32 Degree, (STD.) SHOP NOTE: DELETE STANDARD SIDE SCENES FOR CREDIT PLEASE |
| 32-22-4001 | Flange(s),Scene Lts., Whelen 900 Series Hal. EA. SHOP NOTE: LOCATION: (2) Streetside (2) Curbside |
| 32-22-5042 | Floodlight - (2) Whelen Pioneer Plus PFP2 S-LED Semi-Recess SHOP NOTE: (2) switches in front switch panel, (1) for each side (4) PFP2 dual lamp floodlight - 1041752 (4) PBA203 white semi recessed housing w/chrome flange Mount (2) on each side of the body in line with the standard scene lights SEE PRINT |
| 32-24-0200 | Scenelight Activation - Standard SHOP NOTE: Curbside scenelights will activate when the side entry door is opened. Curbside and streetside rearmost scenelights will activate when the vehicle transmission is placed in reverse. |
| REAR MODULE BODY LIGHTS | |
| 34-10-1400 | Rear Lightbar, Whelen, 86" 4500 Plus Super-LED ILOS SHOP NOTE: |

| PART NO | DESCRIPTION |
|--|---|
| | Lightbar Configuration: (2) Red Corner Linear-LEDs (4) Red 400 series Linear-LEDs (1) RED 400 series Linear-LED--ACTIVATE WITH BRAKE OVERRIRDE (2) Load Lights LED and Lens Configuration: R/R/R/Load/A/Load/R/R/R Wire load lights to activate with rear entry doors and when the vehicle is placed in reverse gear. Install (1) switch in the front switch panel for lightbar. Install (1) switch in the front switch panel for Load Lights only. |
| 34-10-2600 | Arrowstick, Whelen LED Traffic Advisor - Model TANF85 IATS SHOP NOTE: Control Head located: _____ |
| 34-10-LOC1 | Arrowstik, Centered Below Rear Warning Lts. and/or Lightbar SHOP NOTE: INSTRUCTION: Arrowstick/Traffic Advisor to be installed below the rear warning lights/lightbar and centered above the rear door. |
| 34-16-0800 | Rr Bdy Lgts,(2) Mid-Hght, Whelen 900 Super Red LED/lens SHOP NOTE: INSTRUCTION: MOUNT ONE UPPER AND ONE LOWER PER PRINT DRIVER SIDE UPPER PASSENGER SIDE LOWER To shine through rear windows when doors are open. |
| 34-22-0400 | TWO REAR BLUE WHELEN 900 LIGHTS SHOP NOTE: WITH FLANGES TO FLASH IN "X" PATTERN WITH RED LED WHELEN BLUE 900 WITH BLUE LENS DRIVER SIDE LOWER AND PASSENGER SIDE UPPER |
| 34-34-8020 | Flange(s), Addtl. Rear Body Lts, Whelen 900 Series LED |
| VISUAL WARNING DEVICE COMPONENTS | |
| 34-38-0200 | Warning Light Flash Requirements, "F-Spec" Flash Pattern |
| ADDITIONAL VISUAL WARNING DEVICES | |
| 36-08-0550 | PE215 Preemption SHOP NOTE: Without Filter INSTRUCTION: Only works when vehicle is placed in gear. Located in the electrical cabinet as the pre-emption supply for the [2] 4ELTUBES (1) Switch in the switch panel labeled "OPTICOM" |
| 36-09-0600 | Park Override With Reset Cancel Switch, In Front Console SHOP NOTE: CANCEL ALL BUT THE UPPER OUTSIDE FRONT AND REAR LIGHTBAR RED LEDS AND THE SIDE BODY RED 900 LEDS |

| PART NO | DESCRIPTION |
|--|---|
| 36-09-3100 | Wire (1) Lights to Brakes, Brakes Override Flashers SHOP NOTE: INSTRUCTION: Wire CENTER RED LED IN LIGHTBAR light to brake override.This function only active in "Emergency mode Primary and Secondary. |
| 36-10-0510 | Underbody Ground Lights, Weldon 4" LED Each SHOP NOTE: INSTRUCTION: ONE ON EACH CORNER MOMENTARY Switch in front switch panel. LABEL SWITCH "PERIMETER LIGHTS" Weldon, Mounting bracket, OJ10-0503-00, Weldon, Ground light/LED/4" round, 9186-5526-30 Install rock guard over light face. LIGHTS TO ACTIVATE IN PARK WITH THE MOMENTARY SWITCH TO CANCEL THEM |
| 36-12-0600 | Running Board Lts, (2) Whelen TIR 3, Front Stone Guard w/fl SHOP NOTE: INSTRUCTION: Clear LED mounted on the front of stoneguards Activate when cab doors are opened. |
| 36-13-057R | Compt/Entry DOOR LINER Lts, Trucklite 4" LED RED Grommet SHOP NOTE: Install Trucklite 4" round Red LED light with on ALL compartment and entry doors. Each light to flash with each individual door opening. IATS each Location SEE PRINTS |
| 36-14-0710 | C-Channel Rubrail Lts, (6) Whelen LED 4 Red 2 Blue SHOP NOTE: INSTRUCTION: (2) Red LED/Red Lens forward and rearward curbside and streetside. (1) Blue LED/Blue Lens in the center of curbside and streetside. Lights come on with e-master, pri sec. The flash pattern is middle light flashes opposite front and rear. |
| *** BODY DESIGN AND CONSTRUCTION COMPONENTS *** | |
| 40-02-1400 | Body Design & Construction, Alum, 170" L x 96"W |
| 40-02-890S | Side Impact Beam (Std.) |
| 40-03-0105 | Drop Skirt, 6" Both Sides |
| | SHOP NOTE: Includes price of fenderette |
| 40-07-0200 | Compartment & Entry Doors With Door Liner |
| 40-07-0300 | Compartment Door, Inner Liner, ADP (Std.) |
| | SHOP NOTE: Use .063 ADP inner door liner on all compartment doors. |
| 40-08-1000 | Exterior Compartment Depth, 20.75" |
| 40-10-0010 | Protective Coating, Dolphin Noise Reduction |
| | SHOP NOTE: Walls & Ceiling |
| 40-10-0400 | Insulation, Spray Foam, Floor&Stepwell |

| PART NO | DESCRIPTION |
|------------|--|
| | SHOP NOTE: Spray Foam Floor, & bottom and sides of stepwell. 3/8" Reflectix dual air bubble core insulation on walls and ceiling. |
| 40-12-0300 | Vapor Barrier, Smooth Aluminum SHOP NOTE: Install .090 smooth aluminum barrier between the floor and the floor tube structure. |
| 40-12-1200 | Fender Insulator, Flash Patch Liner, Rear Wheelwells |
| 40-14-0200 | Cab Connection, Expanded Bellows SHOP NOTE: INSTRUCTION: |
| 40-18-0600 | Body Mounting, Isomount Technique, 3/4" x 6" Alum, 16-Bolt SHOP NOTE: INSTRUCTION: 3/4" x 6" alum plates, sixteen (16) bolts. Bolts and paired rubber isolators with steel cap and collared mounting nut for each chassis mounting point. |
| 40-20-3700 | EXTERIOR "A" COMPTS - DRIVER SIDE (72-74" HR) SHOP NOTE: LOCATION: Exterior compartments, driver side. |
| 40-26-0700 | D1, Exterior Compartment, 23" W x 84" H |
| 40-32-0200 | D1 Door, Solid, Vertically Hinged |
| 42-04-3100 | D2, Exterior Compartment, 43" W x 33" H SHOP NOTE: MAKE 39" TALL DUE TO DROP SKIRT |
| 42-08-0200 | D2, Doors, Double, Solid, Vertically Hinged |
| 42-10-2400 | D3, Exterior Compartment, Not Required At This Time SHOP NOTE: |
| 42-16-5400 | D4, Exterior Compartment, 43" W x 68" H --OUTSIDE ONLY SHOP NOTE: INSTRUCTION: A notch in the upper left corner, to accommodate 2nd action area. Notch to be approximately 7" from the left side and 27" from the top of the compartment. |
| 42-18-0200 | D4, Doors, Double Solid, Vertically Hinged |
| 44-02-4700 | EXT. COMPTS. - PASS. SIDE (M170) |
| 44-04-7000 | P1, Exterior Compartment, 21" W x 66" H, ALS SHOP NOTE: MAKE 80" TALL MODIFICATION DUE TO DROP SKIRT |
| 44-04-7000 | MAKE P-1 COMPARTMENT THE SAME HEIGHT AS THE CS DOOR |
| 44-06-1000 | P1, Door, Solid, Vertically Hinged |
| 44-12-3600 | Side Entry Door, 32" W x 74" H With Fire Grade ADP Step SHOP NOTE: NOTE: FIRE GRADE ADP DUAL SIDE ENTRY DOOR STEP on the F-450, F-650, C4500, Intl. 4300LP, and FL M2 and Dodge 4500 |
| 44-13-0020 | NOTE: Side Entry Stepwell, Recessed Stepwell |

| PART NO | DESCRIPTION |
|------------|---|
| | SHOP NOTE: NOTE TO PRODUCTION: This unit includes a recessed O2 in the stepwell. |
| 44-13-0100 | Dual Fire Grade ADP Step |
| 44-14-3400 | Door Panel, Side Entry, Three-Piece, Formica & Stainless Steel |
| | SHOP NOTE: INSTRUCTION: Upper - Formica Center - Stainless Lower - Stainless Formica color to match interior. |
| 44-15-0000 | Stepwell Light, Whelen 4" Round LED with Chrome Flange |
| 44-16-1000 | (2) Gloveboxes, Above Side Entry Door |
| | SHOP NOTE: INSTRUCTION: Recessed into headpad. Hinged, flip up acrylic doors with southco grabber latches on the bottom |
| 44-16-1200 | Assist Handle, Side Entry, 1.25" O.D. x 45 Deg Brushed |
| | SHOP NOTE: LOCATION: Interior of side entry door. |
| 44-28-2100 | P4, Exterior Compartment, 17" W x 30" H |
| | SHOP NOTE: |
| 44-30-0200 | P4, Door, Solid, Vertically Hinged |
| 44-32-3400 | P5, Exterior Compartment, 26" W x 84" H (Inside/Outside) |
| | SHOP NOTE: INSTRUCTION: Compartment walls lined with smooth aluminum and rubber matted |
| 44-34-0200 | P5, Door, Solid, Vertically Hinged |
| | * * REAR BODY PATIENT ENTRY DOORS * * |
| 48-12-1000 | Rear Entry Doors, 50" W x 63" H, Dual Handles |
| | SHOP NOTE: INSTRUCTION: Driver side - non-locking. Passenger side - locking. |
| 48-14-3400 | Door Panel, Rear Entry Doors, Three-Piece, Formica & Stainless |
| | SHOP NOTE: INSTRUCTION: Upper - Formica Center - Stainless Lower - Stainless Formica color to match interior. |
| 48-16-0800 | Assist Handle, Rear Entry, 1.25" x 45 Degree Brushed |
| | SHOP NOTE: LOCATION: Interior of rear entry door. |
| 48-22-0600 | (2) Gloveboxes Above Rear Entry Doors |
| | SHOP NOTE: INSTRUCTION: |

| PART NO | DESCRIPTION |
|--|---|
| | Recessed into headpad. One on left side, one on right side. Flip up Acrylic doors with Southco grabber catches at the bottom to secure. |
| 48-24-0600 | Clock - Intellitec Time Manager, Above Rear Entry Doors SHOP NOTE: Centered and recessed in head pad. |
| ** WINDOWS ** | |
| 49-02-0400 | Sliding Window, Side Entry Door, Bronze Glass SHOP NOTE: INSTRUCTION: (1) 20" W x 19" H |
| 49-04-0800 | Fixed Windows, Rear Entry Doors, Bronze Glass SHOP NOTE: INSRUCTION: (2) 20" W x 19" H |
| *** EXTERIOR COMPARTMENT COMPONENTS *** | |
| 50-00-0500 | Exterior Compartments, ADP With "Sweep Out" Design SHOP NOTE: ADP construction with sweepout on floor except rubber lined backboard compartment will have smooth aluminum. Top of the backboard compartment to remain ADP unless otherwise specified |
| 50-00-0501 | SMOOTH DOOR PANELS ON EXTERIOR COMPARTMENTS WITH DA FINISH SHOP NOTE: LIKE UNIT #8362 |
| 50-02-0200 | Exterior Compartments, Gas Charged Door Hold Opens SHOP NOTE: LOCATION: On exterior compartment doors. Gas charged hold open on side entry door. Open greater than 90 degrees where applicable. |
| 50-02-0600 | Exterior Compartment and Entry Doors, Tri-Mark Handles SHOP NOTE: INSTRUCTION: Tri-Mark paddle latches keyed alike. |
| 50-03-0000 | Exterior O2 Vent - On O2 Compartment Door SHOP NOTE: INSTRUCTION: (1) #1031 O/2 vent - exterior compt. door - of O/2 compt. (1) small black plastic vent - interior of compt. door on door liner. |
| 50-04-0400 | Exterior Compartments, Lok-Tyle Floor & Shelves SHOP NOTE: Anti fatigue, anti slip matting with yellow edge cap |
| 50-06-0000 | Rear Door Grabbers, CPI"Grabber" at bottom of door std SHOP NOTE: INSTRUCTION: Bottom of rear entry doors. |

| PART NO | DESCRIPTION |
|------------------------------------|--|
| | For openings up to 145 degrees. |
| 50-06-0400 | Door Seals, Automotive Closed Cell Gasket SHOP NOTE: LOCATION: Exterior compartments & entry doors |
| 50-06-1200 | Power Door Lock System, All Doors - Compartment and Entry SHOP NOTE: INSTRUCTION: Install power door locks with switch in rear license insert |
| 50-06-3400 | Power Door Lock Switch, (2) Additional In Patient Compt. SHOP NOTE: [1] AT REAR DOORS ABOVE THE DUMP SWITCH [1] BY CURBSIDE DOOR PER PRINT |
| 50-06-4200 | Wire Power Door Locks To OEM Chassis Door Locks SHOP NOTE: |
| 50-07-0300 | Stainless Steel Door Sills - All Exterior Compartments SHOP NOTE: Install on upper ledge with 2-sided tape. |
| EXTERIOR COMPARTMENT LIGHTS | |
| 50-08-0200 | Exterior Compartment Lights, Litco w/flange SHOP NOTE: INSTRUCTION: Activated by compartment doors. Includes ALS compt if P-1 door exists. IF no P-1 door, NO ALS lights. Does not include drawers. NOTE TO FAB: Hole size to be 4.5" |
| 50-08-1250 | Compartment lights Pierce LED Tube lights SHOP NOTE: Install Pierce LED tube lights on both vertical sides of each compartment. Drawers are not included. For ALS if No P-1 door is selected, then there shall be no lights in the ALS compartment. IF a P-1 door is available, then install Tube lights on both sides of the P-1 opening. Tube lights to be sized to compartment size by engineering. Lighting should reach 90% of vertical height of each compartment |
| 50-10-0200 | D1, (1) O2 Tank Mount, Stainless Steel Rings - "M" Cylinder SHOP NOTE: INSTRUCTION: Adjustable O2, 7" Base Plate, 702BASE O2, Head Plate, 70202HM O2, Ring, 70298 |

| PART NO | DESCRIPTION |
|--|---|
| 50-12-0400 | D1, Vertical Fixed Divider (s) QTY SHOP NOTE: INSTRUCTION: Install (___) aluminum, spray coated, full height fixed divider. |
| 50-12-1300 | D1, (1) Fixed Shelf SHOP NOTE: LOCATION: MOUNT OVER OXYGEN TANK AS LOW AS POSSIBLE FROM DIVIDER TO WALL #3 |
| 50-14-0200 | D2 Adjustable ADP Shelf, |
| 50-16-2100 | D4, Delete Standard Adjustable Shelf SHOP NOTE: |
| 50-18-2500 | P5, Backboard Divider, Full-Height - spray coated SHOP NOTE: Spray coat both sides of divider. Install in compartment. MOUNT 11" FROM WALL #1 |
| 50-18-3400 | P5, Fixed Shelf SHOP NOTE: MOUNT 40" FROM FLOOR |
| 50-19-0600 | SCBA Mounting Rails (Mounting Plate Not Included) SHOP NOTE: INSTRUCTION: Install [2] SCBA Mounting Rails in P-5 Compartment. Each rail to be welded to the wall. Height of rails to be 40" TO DIVIDE INTO THIRDS |
| 50-20-1200 | Retainer Straps, (2) VELCRO STYLE SHOP NOTE: INSTRUCTION: [1] IN FORWARD SECTION OF THE D-1 COMPARTMENT FROM WALL #1 TO THE DIVIDER CENTERED [1] IN THE P-5 COMPARTMENT FROM THE DIVIDER TO WALL #3 CENTERED |
| No Equipment Hook(s) At This Time (Exterior Compt.) | |
| 50-24-0600 | Grab Rail, 16" - Left Of Side Entry Door |
| 50-24-NOT1 | Grab Rail, Exterior, Service Points in Patient Compartment SHOP NOTE: Two interior service points for the exterior grab handles. |
| 50-32-0800 | Bumper, Rear With 7" Diamondback Flip-Up Step |
| 50-34-0600 | Bumper Pods, Cast Aluminum With Logo SHOP NOTE: Bumper pods are to be even with the rear entry step end. |
| 50-36-0600 | Rear Kick Plate, ADP, Above Rear Bumper Step, Full Width SHOP NOTE: Full width below the rear entry doors, from corner guard to corner guard. |
| 50-36-1600 | "ECK" Body Hardware Preparation |

| PART NO | DESCRIPTION |
|--|--|
| 50-38-0600 | Body Protection, Rear Mudflaps w/logo & "C" Channel Rub Rail SHOP NOTE: "C" channel rub rails full-length to both sides of the body below the compartment doors. |
| 50-40-2200 | Standard Driver and Passenger Step Under Cab Door - Freight SHOP NOTE: FAB PART: Curbside Streetside |
| 50-42-1800 | Rear Corner Guards, ADP, 16.5" SHOP NOTE: ADP cornerguards securely fastened to the body |
| 50-42-5030 | Front Stone Guard, ADP 30" SHOP NOTE: Aluminum Diamondplate stoneguards are to be securely fastened to the body. |
| 50-44-0800 | Fenderettes, Rear, Stainless. for Drop Skirt SHOP NOTE: For 6" Drop Skirts: For 4" Drop skirts For 3" drop skirts: Austin # Right and/or left hand |
| 50-46-3000 | License Plate Holder #LP0002-1, Recessed In Center, LED Ligh SHOP NOTE: INSTRUCTION: With (1) LED Light center mounted. Center in kickplate above rear bumper flip step |
| 50-50-0200 | Undercoating, Chassis & Body (Standard) |
| *** INTERIOR PATIENT COMPARTMENT COMPONENTS *** | |
| 52-05-0600 | Cabinet Glass - 1/4" Smoked Lexan SHOP NOTE: Any mention of plexiglas in this order will be replaced with Lexan, including glove box covers |
| 52-06-0400 | All Interior Latches, Non-Locking Round SouthCo, Stainless SHOP NOTE: INSTRUCTION: All interior cabinet doors to have, Stainless steel non-locking round Southco latches. |
| 52-11-0600 | Cabinet Construction, Std. Material With Formica 5" Radius SHOP NOTE: 5" radius corners on upper Streetside cabinets ONLY ALS TO BE FULL WIDTH |
| 52-12-0011 | Cabinet Drawer and Door Faces, Framed Style ILOS SHOP NOTE: |

| PART NO | DESCRIPTION |
|---------------------------------------|--|
| | ALL CABINET DRAWER AND DOOR FACES ARE FRAMED STYLE |
| 52-28-0100 | Interior Lighting Requirements, VMUX (Motion Sensor) SHOP NOTE: VMUX system is activated by motion sensor. Lighting is controlled by switches and interior light options within the VMUX control switch panel. |
| 52-28-0190 | Dome Light Instruction, Standard Electrical System SHOP NOTE: (2) - 3 position switches in the rear switch panel (1) for each bank of dome lights. (1) On/off switch in the rear switch panel, for both fluorescent lights (ONLY WHEN FLUORESCENT LIGHTS ARE ORDERED) A three-minute time delay system activated by the patient entry doors. |
| 52-28-0505 | Dome Lights, Whelen LED (10) SHOP NOTE: INSTRUCTION: [1] switch in the rear switch panel for each bank of dome lights |
| 52-32-0200 | Ceiling In Patient Compt, Pads Over Center Access SHOP NOTE: INSTRUCTION: The ceiling to have access to antenna bases/leads. Covered by center ceiling pads. |
| 52-34-1000 | Conduit, 2" Flex, Pull Wire & Grommeted SHOP NOTE: INSTRUCTION: (1) 2" flex conduit to run, from behind driver's side cab seat to the 1st action area, behind right side access panel. |
| 52-36-0600 | LED Light, - Surface Mount In 1st Action Area SHOP NOTE: (1) 3-position white/off/red switch installed on the rear switch panel. |
| 52-48-0600 | Timer System For Lights - Rotary SHOP NOTE: INSTRUCTION: Install timer on curbside wall, beside side entry door. Timer to be set up for 0 - 60 minutes. |
| 52-54-2200 | Flooring, With 5" Roll-up |
| 52-54-5000 | Flooring, Cove Molding around ALS (Fed. Amb. Spec Std.) |
| 52-60-0400 | Rear Threshold, 6" Wide Stainless Steel With 2" Skid tape SHOP NOTE: INSTRUCTION: 6" wide stainless steel threshold with 2" wide skid tape covering the threshold screw heads. |
| 52-62-1800 | Interior Risers On Squad Bench & Streetside, Standard Height SHOP NOTE: Standard Height stainless steel on; - the squad bench face and end - the lower section of the streetside cabinet, to just below the bottom of the T-bar. |
| ***INTERIOR COLOR SELECTION*** | |
| 53-02-1200 | Formica Color, Fog (#961) (Grey) |

| PART NO | DESCRIPTION |
|------------|--|
| 53-03-0200 | Matte Formica Finish |
| 53-06-4400 | Flooring Color, Onyx #150, LonCoin II Flecks (Black) |
| 53-33-0400 | Upholstery Color,EVS Brand Gunmetal #MV102&#CN202 Brown/Grey |
| | SHOP NOTE: |
| | INSTRUCTION: |
| | EVS Gunmetal #MV102 Vacuum Formed Cushions For The Following: Tech Seat, CPR Seat & Backrest, Squad Bench Seat & Backrest. |
| | Matching EVS Gunmetal #CN202 For All Trim. |
| | * * * STREETSIDE CABINETS - PATIENT COMPARTMENT * * * |
| 54-02-0100 | Sect 1 - Action Area Wall(s), Brushed Aluminum Laminate |
| | SHOP NOTE: |
| | All Action areas unless otherwise specified |
| 54-02-3800 | Sect 1 - 1st Action Area With 3/4" Lip |
| 54-08-0400 | Sect 1, Radio Cutout 1 With Black Kydex Cover 1st AA |
| | SHOP NOTE: |
| | INSTRUCTION: |
| | (1) cutout for installation of a radio, installed in the 1st action area - with a 1/4" black Kydex cover. |
| 54-12-1000 | Sect 1, No Clock In 1st Action Area At This Time |
| 54-16-2600 | Sect 1, 1st Action Area Overhead Cabinet |
| | SHOP NOTE: |
| | INSTRUCTION: |
| | Fixed center divider and (1) adjustable shelf on each side. |
| 54-18-0600 | Sect 1, Restocking Doors On Overhead Cabinet |
| | SHOP NOTE: |
| | LOCATION: |
| | On the cabinet above 1st action area. |
| | Hinged on top. |
| 54-20-0200 | Sect 1, Handles, Full Length Aluminum |
| | SHOP NOTE: |
| | LOCATION: |
| | On the cabinet above 1st action area. |
| 54-28-4600 | Sect 1, Writing Drawer, |
| | SHOP NOTE: |
| | INSTRUCTION: |
| | Writing drawer below 1st action area. |
| | Round NON locking SouthCo latch to keep closed. |
| 54-36-1000 | Sect 1, Cabinet Below 1st Action Area |
| | SHOP NOTE: |
| | INSTRUCTION: |
| | (1) cabinet below the 1st action area, full width. |
| | Sliding Acrylic doors with full length pull handles. |
| 54-48-0800 | Sect 1, Suction Cabinet, Pull-Out |
| | SHOP NOTE: |
| | INSTRUCTION: |
| | Install a pull-out suction cabinet below the 1st Action Area. |
| 54-49-1200 | Notebook Storage Under 1st AA |
| | SHOP NOTE: |

| PART NO | DESCRIPTION |
|------------|--|
| | <p>INSTRUCTION: An open notebook slot shall be provided under the tray. Slot shall be 14" Deep with a 1/4" lip on the bottom of the opening. 1/4" lip to be formed with drip rail trim piece. SHALL HAVE A 125 VAC OUTLET AND A 12 VOLT OUTLET ON THE BACK WALL</p> |
| 56-02-0400 | <p>Sect 2, Sharps & Waste Compartment - Tilt Out SHOP NOTE: INSTRUCTION: Rearward of the CPR seat with Round NON locking SS Southco latch & hold open. - Provide & install containers. -Part Numbers 8990 Container 8900 Container Use wire basket Flip down door bracket</p> |
| 56-04-0300 | <p>Sect 2, Single Cabinet Above CPR Seat SHOP NOTE: Medtec requires the 43" seat height requirement for AMD Standard 025 head protection!</p> |
| 56-06-1000 | <p>Sect 2, Flip-up Acrylic Door On Cabinet Above CPR SHOP NOTE: (1) strut per flip up section use (1) strut (2) brackets</p> |
| 56-08-1200 | <p>Sect 1, Handles, Round Southco latch SHOP NOTE:</p> |
| 56-26-0400 | Sect 2, 2nd Action Area With 3/4" Lip |
| 56-26-1000 | <p>Sect. 2 2nd Action Area Locking Drug Drawer (s) SHOP NOTE: INSTRUCTION: A locking drug drawer shall be installed below the second action area. -----Countertop to be raised to accommodate the drawer -----Round locking stainless steel southco latch.</p> |
| 58-02-0800 | <p>Sect 3, Rearward Overhead Cabinet SHOP NOTE: INSTRUCTION: Fixed center divider and (1) adjustable shelf on each side.</p> |
| 58-04-0600 | <p>Sect 3, Restocking Acrylic Doors, Rear Overhead Cabinet SHOP NOTE:</p> |
| 58-06-0200 | <p>Sect 3, Handles, Full Length Aluminum SHOP NOTE: LOCATION: On the upper rear streetside overhead cabinet.</p> |
| 58-08-9800 | Sect 3, Lower Rear Streetside Cabinet, 8" Deep Interior |

| PART NO | DESCRIPTION |
|---|--|
| | SHOP NOTE: INSTRUCTION: Lower rear streetside cabinet (upper D4 compartment) Inside access only. 8" deep inside dimension. Includes (2) adjustable shelves. |
| 58-30-9900 | Sect 3, Acrylic Doors, Sliding, Lower Supply Cabinet SHOP NOTE: LOCATION: Lower rear streetside main cabinet. |
| 58-32-9900 | Sect 3, Handles, Full Length, Aluminum SHOP NOTE: LOCATION: Lower rear streetside main cabinet. |
| 58-35-0200 | Sect 3, Glovebox Cabinet, Streetside Rear SHOP NOTE: INSTRUCTIONS: [1] recessed cabinet for (1) gloveboxes. Centered Vertically hinged acrylic door w/Southco SS round latch - hinge on rear (left) side. Locate in lower rear streetside cabinet, by rear doors. MOUNT VERTICAL--SEE PRINT--DO NOT PROTRUDE INTO THE BACKBOARD COMPARTMENT ANY DEEPER THAN NEEDED SEE PRINTS. |
| 58-46-0410 | Sect 3, R/S Exhaust Fan, 6" W x 8" H, 240 cfm Air Flow SHOP NOTE: INSTRUCTIONS: Install (1) standard exhaust fan - curbside rear Install a fan speed switch in rear switch panel. |
| No Heat/Cool or Refrigerator Unit, Required At This Time | |
| 59-02-0011 | MERMAID IV COOLER MODEL MK-SALINE SHOP NOTE: INSTALL A MERMAID MK-SALINE IV COOLER OVER THE CABINET UNDER THE PASS THRU PER PRINT |
| *** BULKHEAD COMPONENTS *** | |
| 60-02-0200 | B1, L/S, Oxygen Compt, Interior Access With O/2 View Window SHOP NOTE: INSTRUCTION: Hinged acrylic door for O/2 view into D-1 compartment. |
| 60-02-0800 | B1, L/S, Electrical Cabinet, Angled SHOP NOTE: INSTRUCTION: A SQUARE cabinet shall house the electrical components. |
| 60-04-0450 | B1, Electrical Cabinet Door, Removable, Soutcho Flip Latches SHOP NOTE: INSTRUCTION: No Hinges REMOVABLE Door vented at the top and the bottom with (2) locking SS SouthCo flip latches, centered at the juncture ILOS. There is NO hinged door. Removable door faces the aisle |

| PART NO | DESCRIPTION |
|------------|--|
| 60-08-0200 | B1, Thermostat, Digital, Pro Air, SHOP NOTE: LOCATION: If not specified will be installed on ANGLED SWITCH PANEL. Forward upper corner. |
| 60-11-0200 | B1/2, Cab/Body Pass-Through SHOP NOTE: LOCATION: Pass-thru between cab and module. INSTRUCTION: There shall be a pass-through access window approx. 16"H x 17.5"W with a sliding acrylic window, in formica covered wood frame. Window handle is on forward side only |
| 60-11-0200 | CABINET UNDER PASS THRU SHOP NOTE: INSTAL A CABINET UNDER THE PASS THRU PER PRINT SIDE HINGED LEXAN DOORS WITH ROUND NON LOCKING LATCHES AT THE TOP FULL LENGTH ALUMINUM HANDLES TWO ADJUSTABLE SHELVES COUNTERTOP TO HAVE 3/4" LIP |
| 60-12-1000 | B1/2, Ducted Heat/AC, Proair #935 Ducted Updraft SHOP NOTE: Requires roof to be painted White Reflectix Insulation in the HVAC cabinet. |
| 60-12-7100 | B1/2, Air Filter, AC Filter on Return Vents |
| 60-14-0800 | B1/2, A/C Condenser, Bottom Mounted, Pro Air SHOP NOTE: INSTRUCTIONS: Install an auxiliary A/C condenser under body. Connect to the standard interior Heater Air Conditioner combination unit. |
| 63-44-9900 | SPECIAL B2, - ALS Cabinet SHOP NOTE: FULL WIDTH ALS CABINET--NO RADIUS TOP 22" TALL FORMICA COVERED UPPER DOORS WITH LEXAN INSERTS [1] ADJSUABLE SHELF [2] ROUND NON-LOCKING SOUTHCO LATCHES AT TOP JUNCTURE BRUSHED FACE ALUMINUM 6" DRUG DRAWER ROLL UP DOORS REAR ROLLER FULL WIDTH NON LOCKING BAR RUN CABINET ALL THE WAY TO THE FLOOR WITH NO LIP ON THE BOTTOM |
| 63-52-0600 | B2, (2) Adjustable Shelf, Bottom ALS SHOP NOTE: LOCATION: Bottom ALS Cabinet |
| 63-70-0100 | B1/2, Radius Cabinet SHOP NOTE: NO HEALTH CENTER--ALS FULL WIDTH |

| PART NO | DESCRIPTION |
|--|--|
| *** PATIENT COMPARTMENT SEATING *** | |
| 64-01-1200 | Vacuumed Formed Upholstery M156/168/170/172 SHOP NOTE: INSTRUCTION: EVS Vacuum formed seats & backrests only. Armrests and all trim panels to be machine stitched using EVS Companion II material. |
| 64-02-0200 | Att Seat - EVS1750 Safe*Line - LH Arm, 2-Pos Swivel Base SHOP NOTE: 2-pt adult seatbelt 188-2 - 2-pos swivel base NO armrest |
| 64-06-1800 | Sect 2, CPR Seat |
| 64-07-1010 | Sect 2, Fold Down Backrest, CPR Seat SHOP NOTE: |
| 64-10-3600 | Sect 2/3, Squad Bench SHOP NOTE: INSTRUCTION: (2) lids with storage under both sections. Gas strut hold opens and paddle latches. Interior floor of storage under squad bench rubber matted |
| 64-14-0200 | Sect 2/3, Back Rests, (2) Above Squad Bench SHOP NOTE: Certain backrests may need to be cut back to accommodate the proper operation of the armrest, gauges, plates, or cabinets. If one is cut back, the other backrest needs cut back as well to match in width. |
| 64-16-0200 | Sect 2, No Posts and Cups Required At This Time |
| 64-18-0800 | Sect 2, Armrest, Padded, Fold Down Style, Squad Bench SHOP NOTE: INSTRUCTION: padded fold down style armrest -- top and side padded. |
| 64-18-1002 | Recessed Grab Handle in the Armrest |
| 64-18-2200 | Sect 2 - Reinforcement Plate. CS Wall - SHOP NOTE: Install 1/4" aluminum backer plates at each mounting point, including the ceiling point. THIS DOES NOT INCLUDE THE CARGO NET. ONLY THE REINFORCEMENT PLATE INSTALLATION |
| 64-20-0400 | Sect 2, Cast O/2 Bottle Storage, Recessed - Head of SQ Bench SHOP NOTE: INSTRUCTION: Vertical storage for (2) "D" cylinders - in curbside stepwell. Recess squad bench and stepwell toward rear. Custom curbside stepwell: 40.25" x 16.75" for PD168A, PD156, FD160 40.25" x 18.75" for AD170A; AD166A (1) Cast OA0008-1 Dual O/2 Wall Mount (1) Cast OA0005-1 Dual O/2 Base |
| 64-22-0600 | Sect 2, Sharps/Waste, Front of Squad Bench, Slide-Out Drawer SHOP NOTE: |

| PART NO | DESCRIPTION |
|---|---|
| | INSTRUCTION: At head end on aisle side. Sharps & waste containers will be installed. Drawer with round locking SS Southco latch. - Provide & install containers. -Medtec Part Numbers 8990 Container 8990 Base 8900 Container 8900 Base |
| 64-24-0200 | Front Seatbelt Buckles on Squad Bench Face SHOP NOTE: Install Seatbelt buckles on the face of the Squad Bench. |
| *** CURBSIDE CABINETS - PATIENT COMPARTMENT *** | |
| 68-16-0200 | Sect 3, Inside/Outside Access Into P-5, Formica covered Door SHOP NOTE: INSTRUCTION: Formica covered door - vertically hinged, rearward. USE RECTANGULAR SOUTHCO LATCH AT TOP PER PRINT |
| 68-16-0201 | VENTS IN P-5 DOOR SHOP NOTE: INSTALL TWO VENTS--ONE TOP AND ONE BOTTOM IN THE INSIDE/OUTSIDE DOOR PER PRINT--SAME VENTS AS ON THE ELECTRICAL CABINET DOORS |
| *** PATIENT COMPARTMENT EQUIPMENT/COMPONENTS *** | |
| 70-02-1000 | IV Holders, (4) Cast Products #2008-1, Ceiling Mounted SHOP NOTE: LOCATION: (2) over cot (2) over squad bench |
| 70-08-0400 | IV Warmer, (1) Smithworks, 12 Volt, Specify Location SHOP NOTE: TO B E DETERMINED AT PRE-BUILD |
| 70-10-0700 | Cot Mount, Stryker #6370 Single Position, Floor Mount SHOP NOTE: INSTRUCTION: For Cot Model: _____ (for positioning of cot mounts only) |
| 70-14-0400 | Cot Mount Location, Center Mount SHOP NOTE: |
| 70-18-9905 | No Special Cot accessories at this time |
| 70-18-LOC1 | Cot Mount Location, Std. |
| 72-02-0100 | Rear Entry Assist Handles, (2) Black Molded (Standard) SHOP NOTE: LOCATION: Inside rear module |
| 72-02-1200 | Assist Rails, (1) 90" x 1.25", (1) 60" x 1.25" O.D, Brushed |

| PART NO | DESCRIPTION |
|---|---|
| | SHOP NOTE: INSTRUCTION: (1) 90"x 1.25" - over cot. (1) 60" x 1.25 " - over squad bench. |
| 72-10-0200 | Signs, "No Smoking Oxygen Equipped" & "Fasten Seatbelts" SHOP NOTE: LOCATION: (1) on 1st action area wall. |
| * * * MEDICAL OXYGEN & ENVIRONMENTAL SYSTEMS * * * | |
| 74-02-0200 | Oxygen System, 3000 Liters Minimum |
| 74-02-0650 | Oxygen, (3) Outlets - (1) AA, (1) Squad Bench, (1) Ceiling SHOP NOTE: INSTRUCTION: (1) 1st AA (1) Squad Bench, head end of the overhead cabinet (1) Ceiling SEE PRINTS |
| 74-04-0800 | Oxygen Outlets, Ohio Style |
| 74-06-0600 | Flowmeter, (1) Oxygen, Gravity Type SHOP NOTE: LOCATION: SHIPPED LOOSE |
| 74-10-0600 | Regulator, Oxygen SHOP NOTE: LOCATION: On O/2 hose in designated oxygen compartment. |
| 74-14-0600 | Gauge, Digital Oxygen Content With Alarm SHOP NOTE: LOCATION: In 1st action area. |
| 74-18-0400 | Oxygen Shut-Off, Electric Solenoid With Manual Bypass SHOP NOTE: INSTRUCTION: Manual by-pass valve on 1st action area wall. (1) switch in the rear switch panel. |
| 74-20-0800 | Suction & Aspiration Systems, SSCOR/Vacuum Pump D2 SHOP NOTE: INSTRUCTION: (1) SSCOR 23002 disposable canister, injection molded plastic bracket and wall-mount SSCOR 22000 vacuum gauge and outlet on 1st action area wall. Install the vacuum pump in the D-2 compartment, in a metal cage. (1) "on/off" switch in the rear switch panel, for Suction pump. SEE PRINTS Canister Bracket Panel Mount |
| 74-22-0200 | Sharps & Biohazard Racksack With Red Medical Bags SHOP NOTE: Ship Loose |

| PART NO | DESCRIPTION |
|--|--|
| *** COMMUNICATION & LOOSE EQUIPMENT *** | |
| 76-02-0600 | Patient Code Signal System, With (3) Switches & Buzzer SHOP NOTE: LOCATION: Cab console and rear switch panel. |
| 76-06-0400 | Radio Antenna Pre-Wire, (3) Base, Power, Ground & Coax SHOP NOTE: INSTRUCTION: Antenna/Radio (3) bases and coax. LABERL 1-2-3 FROM FRONT TO BACK Power and ground wires. Run from: Center front of module roof. Center center of module roof. Center rear of module roof. Run to: [2] TO FRONT CONSOLE [1] TO ACTION AREA RADIO PANEL NOTE: ANTENNAS NEED TO BE AT LEAST 18" DISTANCE APART. |
| 76-08-0400 | Cell Phone/Radio Equip, (1) Each Pwr & Grnd, Coax Cable SHOP NOTE: INSTRUCTIONS: (1) Antennae base - Run from: Center rear of module roof. Run to: REAR ELECTRICAL CABINET PLEASE NOTE: ANTENNAS NEED TO BE AT LEAST 18" APART. |
| 76-08-9900 | TWO RADIO ANTENNAS ADDITIONAL SHOP NOTE: ONE FROM PASSENGER SIDE CAB ROOF TO FRONT CONSOLE--MODEL MAXRAD BMML 195 ONE FROM DRIVER SIDE CAB ROOF TO FRONT CONSOLE FOR MDT PLEASE LABEL |
| 78-02-0600 | (2) Fire Extinguishers, ABC 5 lb With Mounting Brackets SHOP NOTE: LOCATION: SHIPPED LOOSE |
| 78-08-0000 | Ship Loose Locking Sharps Disposal System SHOP NOTE: Ship Loose Kendall 85161H in room sharps disposal unit. |
| 78-08-1000 | DOT Triangles, Ship Loose (std.) |
| *** PAINT *** GRAPHICS | |
| 80-02-0200 | No Chassis Repaint Required At This Time (OEM Only) |
| 80-04-0200 | Body Surface Preparation with Corrosion Inhibitor |
| 80-04-0400 | Paint Preparation & Processes |
| 80-04-1200 | Body Paint Color, Two-Tone OEM Color Upper/Custom Color Lower SHOP NOTE: INSTRUCTION: LOWER TO BE RED TO BOTTOM OF THE SIDE LIGHTS UPPER AREA TO BE BLACK SEE AND FOLLOW THE PRINTS TO MATCH THE OEM CAB COLORS |

| PART NO | DESCRIPTION |
|--|--|
| 80-07-0000 | Roof Paint Color, Single Color White SHOP NOTE: Flat part of the Roof to be painted white with the Ducted Heat/AC , not to be seen from the ground. |
| 84-05-0101 | + Select Optional Paint Design *** GRAPHICS/LETTERING M-SERIES *** |
| 89-10-0010 | Vinyl Package, M-Series Single Band Only, Std. |
| 89-20-0130 | 1/4" Reflective Pinstripe 3M SHOP NOTE: Indicate Color: GOLD SCOTCHLITE ON EACH SIDE OT THE REAR CHEVRONS PER PRINT |
| 89-20-0250 | 1" Reflective Pinstripe 3M SHOP NOTE: Indicate Color: BLACK SCOTCHLITE SEPARTED 1" WITH RED PAINT ABOVE AND BELOW THE 6" BAND |
| 89-20-0480 | 6" Vinyl Safety Stripe 3M SHOP NOTE: Indicate Color: BLACK SCOTCHLITE |
| 89-32-0070 | Exterior Rear Barricade w/ Doors 1 Color SHOP NOTE: Indicate Color: BLACK SCOTCHLITE MAKE THE STRIPE 5 1/2" WIDE TO BE BORDERED WITH 1/4" GOLD PINSTRIPES BOTH SIDES |
| 89-40-0100 | 1/2" Perimeter Stripe Side Door, Reflective SHOP NOTE: Indicate Color:RED |
| 89-40-0120 | 1/2" Perimeter Stripe Rear Doors, Reflective SHOP NOTE: Indicate Color:RED |
| 89-80-1131 | Pinstripe, 3/4" W -"C" Style Rubrail, Reflective SHOP NOTE: INSTRUCTION: Install 3/4" wide white reflective stripe 680-010 through the center of the "C" style rubrail. |
| 89-90-0011 | Install Roof SOL & Ship Loose Ambulance Package Installation SHOP NOTE: Roof SOL will be centered on module unless otherwise specified. |
| *** DELIVERY / END USER DOCUMENTATION *** | |
| 90-02-0300 | Vehicle Operator's Manual, Hard Cover Binder - AD/M |
| 90-06-0400 | New Vehicle Owner's Manual |
| 90-06-0600 | Operating Instructions, DVD |
| 90-06-0800 | Electrical Schematics CD |
| 90-07-0200 | Fuel, Fill |
| 92-02-0200 | Medtec Standard Warranty |

| PART NO | DESCRIPTION | |
|------------|---|-------------------|
| | DEALER ===== DEALER ===== DEALER | |
| 97-01-0100 | AIR PACK BRACKETS | |
| 98-01-1800 | LETTERING PER SPECIFICATION | |
| | SHOP NOTE: | |
| | SIGN GOLD ENGINE TURN | |
| 98-02-0100 | CORIAN COUNTERTOP IN MAIN ACTION AREA--grey spec | |
| 98-02-0200 | CORIAN COUNTER TOP IN SECOND ACTION AREA--grey spec | |
| 99-01-0000 | FIRE VULCANS W/LED TAILLIGHTS W/MEDTEC PRE-WIRE | |
| 99-01-0600 | EXTRA BALL TYPE FLOWMETER AND ADAPTER | |
| 99-01-0702 | PARAMEDIC DESIGN WALL UNIT--TWO SECTION | |
| 99-01-1000 | LIGHT ACTIVATION PACKAGE | |
| 99-01-1100 | DOOR BUZZER PACKAGE | |
| 99-01-1400 | DUAL FRONT AND REAR MOD-DISCONNECT SWITCHING | |
| 99-98-2901 | STRYKER TRENDELENBERG / KNEE GATCH FOR MX-PRO COT | |
| 99-98-4000 | STRYKER FOWLER O2 HOLDER AND SMART CARGER BRACKET | |
| 99-98-4300 | STRYKER 3 STAGE IV POLE PATIENT RIGHT OR LEFT | |
| 99-98-4800 | STRYKER POCKETED POUCH STO-NET AT HEAD OF COT #6082 | |
| 99-98-4850 | STRYKER #6500 EQUIPMENT HOOK | |
| 99-98-4900 | STRYKER HEAD FLAT POUCH | |
| 99-98-5100 | STRYKER POWER PRO #6500 XT COT W/SMART BATTERY | |
| 99-98-6000 | TOP HATS AND NUT COVERS FOR MEDIUM DUTY TRUCKS | |
| 99-99-5000 | INSTALL COAT HOOKS AND CUSTOMER AIR PACKS BRACKETS | |
| 99-99-9600 | INSTALL CUSTOMER SUPPLIED RADIOS | |
| 99-99-9700 | INSTALL CUSTOMER SUPPLIED LAPTOP MOUNTS | |
| 99-99-9800 | FACTORY INSPECTION TRIP | |
| 99-99-9901 | DELIVERY FROM BRADENTON, FLORIDA | |
| | Total | 170,289.00 |

